



Error code table

Vehicle	BMW / 325 xi / 09/2000 - / Saloon, All-wheel
Country of manufacture	D
Cubic capacity/Power	2.5 / 141 kW
Motor tag	25 6 S5
RB key	BMW 534
Sector	All
System	Central electronics / ZE 1.0

Code	Error	Error type
00	Control unit	faulty
01	Fuse for washer pump, interior lighting	faulty
02	Fuse for central locking	faulty
03	Crash signal	
06	Signal from anti-theft warning system	faulty
07	Signal from anti-theft warning system	faulty
08	Fuse for power windows	faulty
09	Left-front power window: relay or motor	faulty
0A	Right-front power window: relay or motor	faulty
0B	Left-rear power window: relay or motor	faulty
0C	Right-rear power window: relay or motor	faulty
0D	Left-front power window: antitrap mechanism	faulty
0E	Right-front power window: antitrap mechanism	faulty
0F	Left-rear power window: antitrap mechanism	faulty
10	Right-rear power window: antitrap mechanism	faulty
20	Control unit	faulty
21	Control unit	faulty
22	Control unit	faulty
23	Control unit	faulty
24	Central locking: relay for locking function	faulty
25	Central locking: relay for unlocking function	faulty
26	Central locking: relay for secure function	faulty
28	Central locking: relay for locking function	faulty

Error code table

12/3/2005
3:11:37 AM

29	Central locking: relay for unlocking function	faulty
2A	Central locking: relay for secure function	faulty
2B	Central locking: relay for locking left-front door	faulty
2C	Left-front power window: relay	faulty
2D	Right-front power window: relay	faulty
2E	Left-rear power window: relay	faulty
2F	Right-rear power window: relay	faulty
30	Communications	faulty
31	Interval switch: step switch	faulty
32	Interval switch: step switch	faulty
33	Windscreen wiper: blocking protection active	faulty
36	Windscreen wiper stage 1: relay or motor	faulty
37	Windscreen wiper stage 2: relay or motor	faulty
38	Windscreen washer pump	faulty
3B	Interior lighting	faulty
3D	Hatchback-lid locking relay or motor	faulty
3F	Rear-window unlocking: relay or motor	faulty
41	Anti-theft warning system: inclination sensor	faulty
42	Anti-theft warning system: interior protection	faulty
43	Anti-theft warning system: interior protection, rear	faulty
44	Control unit	Not coded
45	Central locking: driver-door switch	faulty
46	Central locking: front-passenger door switch	faulty